



ELD Quick Guide

AI ELD

ELD System Setup

Download and install the ELD App

1. Open the app distribution platform on your mobile device.
2. Search for the ELD app.
3. Download and install it on your mobile device.

Log in

1. Your fleet manager must create your user credentials and provide them to you.
2. Open the app and enter your username and password.

Connect the App to the ELD Hardware

1. Make sure Bluetooth on your mobile device is on.
2. Select your vehicle from the available list.
3. Confirm that the Bluetooth connection has been established.



Logging Your Duty Status

Access the Main Screen

Once you've successfully logged in to the ELD app, you will land on the main screen. This screen provides an overview of your current duty status and other vital information.

Update Your Status

To change your duty status, locate and tap on the Status button. A list of available statuses, including Off Duty, Driving, On Duty, Sleeper will appear. Yard Moves, and Personal Use will be available if pre-configured by your fleet manager. Choose the appropriate status by tapping on it.



Managing HOS Records

Access Your Logs

Navigate to the Logs section within the ELD app to gain access to your electronic HOS records. This feature allows you to review your duty status changes over different dates, providing a comprehensive overview of your driving activities.

Detailed Information

To see detailed HOS records, simply tap on a specific date. This action will open up a detailed view of each duty status you've recorded. You'll find essential information such as the exact time, duration, and specific locations, etc.

Edit with Caution

The ELD app allows edits to be made in accordance to FMCSA guidelines. It is important to note that automatically recorded driving time cannot be changed under any circumstance. However, you can still make adjustments to other duty status entries. To edit, tap on the pencil icon beside the respective entry. If you need to insert a past duty status that you inadvertently missed, use the "Create" button to add it.

Driver Vehicle Inspection Reports (DVIRs)

Easily initiate the process of creating pre- or post-trip inspection reports by tapping the "+" sign. This intuitive action ensures that you comprehensively document the condition of your vehicle before and after each journey, enhancing safety and compliance.

Take a proactive step in vehicle maintenance by promptly notifying your mechanic of any identified defects or issues from the inspection. This helps to keep your vehicle in optimal working condition, contributing to efficient operations and reduced downtime.

 **Thursday, June 15th**

Vehicle: #24

 No defects

Trailers: Gg

 No defects



DOT Inspection Mode

Access the DOT Inspection mode via the side menu

Facilitate seamless roadside inspections by providing your device to officers. They can easily navigate through your logs, ensuring a hassle-free inspection process.

When prompted by the officer, tap the "Data Transfer" option within the DOT Inspection mode. This will transfer your logs to Web Service.

There is also an option to email logs to certain email address.

Offline Mode

Experience uninterrupted performance even when your device encounters a loss of cellular signal. The app seamlessly transitions to an offline mode, ensuring your logging process remains unaffected.

When connectivity is restored, rest assured that all logs recorded during the offline period will be automatically synchronized with the app. This intelligent feature guarantees that your data is always up-to-date and accurately reflects your duty status.

Additionally, you have the option to manually prompt synchronization with the server by tapping the "Sync" icon in the app's action bar.

